



Quick Start Card

PRECISION™ SERIES
AND ENERGY™ SERIES
TREADMILLS

GETTING STARTED

PRECISION SERIES AND ENERGY SERIES TREADMILLS


As you get to know your new Precor treadmill and your own fitness goals, you'll use the advanced features of the treadmill more often. To begin with, though, here's an easy way to start out.

NOTE: These instructions assume that your treadmill has been completely installed and set up.



WARNING: Read through ALL of the safety information in the Owner's Manual, and make sure that the treadmill is properly connected to the electrical supply in your house, before you use the treadmill.


TO GET STARTED WITH YOUR NEW PRECOR TREADMILL:








STEP 3: Attach the safety clip securely to your clothing.



STEP 4: Place one foot on each of the rails on either side of the treadmill belt.




STEP 5: Touch the QuickStart button (manual operation) or the Go button (start today's featured workout).



STEP 6: After the console has displayed its countdown and the belt has started to move, step onto the belt.



STEP 7: Use the controls on the console to adjust the incline angle of the treadmill and the speed of the belt.



CAUTION: Before beginning any fitness program, see your physician for a thorough examination. Ask your physician about the appropriate target heart rate for your fitness level.

CHOOSE A WORKOUT

- Determine your level of fitness: beginner, intermediate, or advanced.
- Determine your immediate goal: endurance training, cardio-conditioning, or weight loss.

If you are a beginner, start with a cardio-conditioning workout to gradually adjust your body to the demands of exercise. Over a recommended eight-week period, you will increase your endurance and strength.

For all fitness levels, plan to exercise at an appropriately challenging pace for 20 to 30 minutes a day. Wear a chest strap to monitor your heart rate. Supplement your plans with fitness workouts from the Precor web site (www.precor.com). The Precor web site also provides expert advice to help you reach your fitness goals.

MONITOR YOUR HEART RATE

The SmartRate and heart rate displays provide visual cues that help you adjust your fitness routine to reach your goals. Use these features to keep your heart rate within the target zones.

Wear a Chest Strap

During a workout, the heart rate features appear on the display when you wear a chest strap. To receive an accurate reading, the chest strap needs to be in direct contact with your skin. After you put on the chest strap, face the display console for a minimum of 15 seconds. This allows the receiver in the console to recognize the signal from the chest strap.

 Carefully dampen the back of the strap with tap water (Diagram A).

IMPORTANT: Do not use deionized water. It does not have the proper minerals and salts to conduct electrical impulses.

- 2. Adjust the strap and fasten it around your chest. The strap should feel snug, not restrictive (Diagram B).
- Make sure that the chest strap is right side up, lies horizontally across your chest, and is centered in the middle of your chest (Diagram C).







Diaaram A

Diagram B

Diagram C

When these steps are complete, you are ready to view your heart rate.

Touch-Sensitive Handrail Grips

Several Precor products incorporate touch-sensitive heart rate grips on the handrails. If you prefer to use the touch-sensitive handrail grips, use both hands. Make sure both hands are moist (not dry) and avoid grasping the sensors too tightly.

Note: For the best heart rate monitoring results, wear a chest strap.

SMARTRATE® FEATURES

When you begin an exercise session, a blinking segment in the SmartRate display appears if you entered your age during the setup phase. The blinking segment indicates the current zone of your heart rate.

The calculation used for the heart rate target zone is your maximum aerobic heart rate:


207 - (your age x 0.67), multiplied by a percentage.

For the ideal weight loss range, your heart rate should remain between 55% and 69% of your maximum

aerobic heart rate. To improve your overall cardiovascular and respiratory fitness level, maintain your heart rate between 70% and 85% of your maximum aerobic heart rate. For the greatest benefits, maintain your heart rate in either zone for 30 minutes or more at least three times a week.

CAUTION: Your heart rate should never exceed 85% of your maximum aerobic heart rate or go above your target zone (Diagram D).

Diagram D: Heart Rate Target Zones



COOL DOWN AFTER YOUR WORKOUT

Cooling down is an important aspect of your workout because it helps reduce muscle stiffness and soreness by transporting excess lactic acid out of the working muscles. Cooling down for at least three minutes helps provide a smooth transition that allows your heart rate to return to its normal, non-exercising state.

20031142nd Avenue NE | P.O. Box 7202 Woodinville, WA USA 98072-4002 www.precor.com P/N 303169-111 | ©2014 Precor Incorporated







Enerc SERIES TREADMILLS

TRM 445

TRM 243

Important Safety Instructions

When using the equipment, always take basic precautions, including the following:

- Read all instructions before using the equipment. These instructions are written for your safety and to protect the unit.
- Before beginning any fitness program, see your physician for a complete physical examination. Il est conseillé de subir un examen médical complet avant d'entreprendre tout programme d'exercise. Si vous avez des étourdissements ou des faiblesses, arrêtez les exercices immédiatement.

DANGER

To reduce the risk of electrical shock always unplug the treadmill from the electrical outlet immediately after using and before cleaning.

WARNING To reduce the risk of burns, fire, electric shock, or injury, take the following precautions:

- Do not allow children, or those unfamiliar with the operation of the equipment, on or near it. Do not leave children unsupervised around the unit.
- Never leave the equipment unattended when it is plugged in. Unplug the equipment from the power source when it is not in use, before cleaning it, and before acquiring authorized service.
- When the equipment is not in use, disconnect it by turning the power switch to the Off position, and then remove the power plug from the power outlet. Alternatively, you can prevent inappropriate use by disconnecting the magnetic stop key and removing it from the location where the equipment is installed.

Important Safety Instructions

- Assemble and operate the equipment on a solid, level surface. Locate the equipment a few feet from walls or furniture. Keep the area behind the equipment clear.
- Never operate the unit if it is damaged, not working properly, when it has been dropped, or has been dropped in water. Return the equipment to a service center for examination and repair.

DANGER The treadmill must be connected to a dedicated, grounded circuit (refer to Grounding Instructions).

- Keep the power cord and plug away from heated surfaces.
- Keep all electrical components, such as the power cord and power switch, away from liquids to prevent shock.
- Do not operate the equipment where aerosol (spray) products are being used or where oxygen is being administered.
- Do not use outdoors.

- Maintain the equipment in good working condition (refer to *Maintenance*). Make sure that all fasteners are secure and the running belt is clean and running smoothly.
- Do not attempt to service the equipment yourself except to follow the maintenance instructions found in this manual.
- Never drop or insert objects into any opening.
 Keep hands away from moving parts.
- Use the equipment only for its intended purpose as described in this manual. Do not use accessory attachments that are not recommended by the manufacturer, as such attachments may cause injuries.
- Do not set anything on the handrails or hood. Place liquids, magazines, and books in the appropriate receptacles.
- Do not rock the unit. Do not lean or pull on the console at any time. Do not stand on the hood.
- Wear proper exercise clothing and shoes for your workout and avoid loose clothing. Do not wear shoes with heels or leather soles. Check the soles of your shoes and remove any dirt and embedded stones. Tie long hair back.

- Use care when getting on or off the equipment. Always grasp the handrail when stepping on the running belt and keep the initial speed at or below 1 mile per hour (mph) or 1.6 kilometers per hour (kph). Never step off the treadmill while the running belt is moving.
- Before the running belt begins moving (before your workout), and after it stops (at the end of your workout), straddle the belt by placing your feet firmly on the right and left staging platforms.
- Keep your body and head facing forward. Never attempt to turn around on the treadmill.
- The safety clip must be attached at waist level before your workout. A lanyard connects to the red magnetic stop key within the STOP switch. If you encounter difficulties, a strong tug on the lanyard disengages the magnetic stop key and stops the running belt.
- Do not overexert yourself or work to exhaustion. If you feel any pain or abnormal symptoms, stop your workout immediately and consult your physician.

Safety Approvals for Cardiovascular Equipment

Precor equipment has been tested and found to comply with the following applicable safety standards.

Cardiovascular Type Equipment:

 CAN/CSA, IEC 60335-1 (Household and similar electrical appliances - Safety)

Important Safety Instructions 3

Grounding Instructions

The equipment must be grounded. If the equipment malfunctions or breaks down, grounding provides a path of least resistance for electric current, which reduces the risk of electrical shock. The equipment is equipped with a power cord having an equipment-grounding conductor and a grounding plug. The plug must be inserted into an outlet that is properly installed and grounded in accordance with all local codes and ordinances. Failure to properly ground the equipment could void the Precor Limited Warranty.

DANGER Improper connection of the

equipment-grounding conductor can result in a risk of electric shock. Check with a qualified electrician or service person if you are in doubt as to whether the unit is properly grounded. Do not modify the plug provided with the equipment. If it does not fit the outlet, get a proper outlet installed by a qualified electrician.

120 V Units Designated for North American Markets

The unit must be connected to a dedicated, grounded circuit. A 15 amp dedicated circuit is required, but a 20 amp dedicated circuit is recommended. The power outlet must have the same configuration as the plug. No adapter should be used with this product.

Radio Frequency Interference (RFI)

Federal Communications Commission. Part 15

This fitness equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. The equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the owner's manual instructions, may cause harmful interference to radio communications

If the equipment does cause harmful interference to radio or television reception, which can be determined by turning the unit off and on, you are encouraged to try to correct the interference using one or more of the following measures:

- Reorient or relocate the receiving antenna for your TV, radio, VCR, DVR, etc.
- Increase separation between the unit and the receiver (TV, radio, etc.).
- Connect the equipment into a different power outlet on a dedicated circuit different from the one used by the receiver (TV, radio, etc.). No other appliance should be plugged into the same power outlet as the equipment.
- Consult an experienced radio/TV technician for help.

WARNING Per FCC rules, changes or modifications not expressly approved by Precor could void the user's authority to operate the eauipment.

Important Safety Instructions

Canadian Department of Communications

This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus set out in the Radio Interference Regulations of the Canadian Department of Communications.

Le présent appareil numérique n'émet pas de bruits radioélectriques dépassant les limites applicables aux appareils numériques de la class B prescrites dans le Règlement sur le brouillage radioélectrique édicté par le ministère des Communications du Canada.

ATTENTION: Haute Tension Débranchez avant de réparer

Obtaining Service

You should not attempt to service the equipment except for maintenance tasks as described in this manual. The equipment does not contain any user-serviceable parts that require lubrication. For information about product operation or service, see the Precor web site at www.precor.com.

Should you need more information regarding customer support numbers or a list of Precor authorized service centers, visit the Precor web site at www.precor.com.

For future reference, write the model number, equipment serial number, console serial number, and date of purchase for your unit in the space provided.

| Model number: | | |
|-------------------------|--|--|
| quipment serial number: | | |
| Console serial number: | | |
| Date purchased: | | |

The equipment serial number is located at the lower front edge of the treadmill cover, near the power switch and cord.



Figure 1: Treadmill serial number label position

The console serial number is located inside the USB connector compartment on the back of the console. You will need to open the cover of this compartment to see the number.




Figure 2: Console serial number label position

Important Safety Instructions

Table of Contents

| Important Safety Instructions | 1 |
|-------------------------------------|----|
| Safety Approvals for Cardiovascular | |
| Equipment | 3 |
| Grounding Instructions | 4 |
| Radio Frequency Interference (RFI) | 5 |
| Obtaining Service | 6 |
| Treadmill Safety Features | 10 |
| Location | 10 |
| Turning the Unit On and Off | |
| Using the Treadmill Safety Clip | |
| Using the Handrails | |
| Getting Started | 15 |
| Using the Console Controls | 17 |
| Connecting Your Apple Device | 20 |

| Setting Up Your Equipment | 22 |
|--------------------------------------|----|
| Measuring Your Heart Rate | 26 |
| Using SmartRate | |
| Getting Accurate Heart Rate Readings | 30 |
| Setting Your Target Heart Rate | |
| Troubleshooting Heart Rate Readings | |
| Choosing and Completing a Workout | 34 |
| Choosing a Workout | 36 |
| Available Workouts | 40 |
| Changing Settings and Metrics While | |
| You Work Out | 47 |
| Finishing Your Workout | 54 |
| Saving Your Workout | |
| Checking Your Weekly Progress | |
| Tracking Your Progress with Preva | |
| Creating User Profiles | 59 |
| Choosing a User Profile | |
| Changing Your Default Settings | |
| Deleting User Profiles | |

| Changing the System Settings | | |
|-------------------------------|----|--|
| Retrieving System Information | 68 | |
| Displaying the Error Log | 69 | |

| Maintenance | 70 |
|-------------------------------|----|
| Inspection | 70 |
| Cleaning the Equipment | 7 |
| Storing the Chest Strap | 7 |
| Checking the Alignment of the | |
| Running Belt | 72 |
| Adjusting the Running Belt | 73 |
| Long-Term Storage | 74 |

Table of Contents 9

Treadmill Safety Features

The treadmill is equipped with certain items that, when used properly, help sustain a safe and enjoyable workout. These items include:

- Safety clip and magnetic stop key
- Handrails
- Power switch

Important: Before exercising, review the Important Safety Instructions found at the beginning of this manual.

Location

It is important to keep the area around the treadmill open and free from encumbrances such as other equipment. The minimum space requirements needed for user safety and proper maintenance are as follows:

- An area three feet wide by six feet long (one meter wide by two meters long) must be left open directly behind the running belt.
- Three feet (one meter) of space should be available on either side of the equipment.

Turning the Unit On and Off

To turn the unit on and off, use the power switch located underneath the front of the unit, near the power cord connection. Refer to the following figure and the product label to see the location of the switch.

Important: When the unit is not being used, turn it off.




Figure 3: Power switch location

Treadmill Safety Features 11

Using the Treadmill Safety Clip

The treadmill is equipped with two different stop functions, which behave as follows:

If the user ... Then the And the console ...

> treadmill helt ...

Pulls on the Slows to a Shows the words "Please lanyard

stop

Replace the Stop Key."

attached to the safety clip and removes the stop key

Presses down on the red STOP stop

switch

Slows to a Shows that the exercise

workout is paused. Pressing the button again ends the

workout and displays the workout summary. Pressing it a third time returns the user to

the home screen.

The following figure shows the location of the STOP switch and the stop key.




Figure 4: STOP switch, stop key, and safety clip

CAUTION: When you work out, ALWAYS attach the safety clip to your clothing. A position near your waistline normally works best.

If the stop key is removed during exercise, perform the following steps:

1. Reattach the safety clip if necessary.

deleted.

- 2. Insert the stop key into the recess on the STOP switch, returning it to its normal position.
- Wait for the treadmill to reset itself.
 Note: If the stop key is removed from the STOP switch, all information about the current workout is

4. Start the workout from the beginning, reducing the time as needed to account for the amount of exercise that has been completed.




Figure 5: Attaching the safety clip

Treadmill Safety Features 13

Using the Handrails

To maintain your balance, always grasp a handrail extension when you step on or off the treadmill, and when you use the keypad.

To learn more about the touch-sensitive grips, refer to *Measuring Your Heart Rate*.

Getting Started

As you get to know your new Precor treadmill and your own fitness goals, you'll use the advanced features of the treadmill more often. To begin with, though, here's an easy way to start out.

Note: These instructions assume that your treadmill has been completely installed and set up (refer to *Setting Up Your Equipment*).

WARNING

Read through ALL of the safety information in this manual, and make sure that the treadmill is properly connected to the electrical supply in your house, before you use the treadmill.

To get started with your new Precor treadmill:

- 1. Turn the treadmill on if necessary.
- Step onto the treadmill.
- 3. Attach the safety clip securely to your clothing (refer to *Using the Treadmill Safety Clip*).
- 4. Place one foot on each of the rails on either side of the treadmill belt.
- 5. Touch one of the following buttons:
 - Go (to start the suggested workout)
 - QuickStart
- 6. After the console has displayed its countdown and the belt has started to move, step onto the belt.

Getting Started 15

7. Use the motion controls to adjust the incline angle of the treadmill and the speed of the belt.



Figure 6: Motion controls

- 8. If you need to end your workout early, do one of the following things:
 - Press the **STOP** switch just below the console three times.
 - On the console screen, touch Pause, then Finish, then Home.

Using the Console Controls

The figure and table on the following page show the main areas on the front surface of the console. You can reach any menu, setting, control, or feature of your equipment by using these areas.

Using the Console Controls 17



Figure 7: Controls and display areas

Table 1. Console feature descriptions

Area Purpose



The **display screen** shows you what the equipment is currently doing and how you are using it. As you work with the equipment, the available options appear next to the buttons along the left and right edges of this area. If you've connected a player to the console and are using it while you work out, the current track information appears along the top edge.

Note: You must use your player's screen to display video, but you can play its audio portion through the console.



Touch the capacitive **buttons** to enter your personal settings, set up the equipment, and choose workouts. Depending on what you're doing, these buttons have different names and purposes. The names of the buttons appear next to them on the display screen.

| Area | Purpose | | |
|------|--|--|--|
| 3 | The level indicators show how intense your workout is at the moment. The indicator on the left shows the incline angle and the indicator on the right shows your speed. | | |
| 4 | The motion controls set the intensity levels shown on the level indicators. | | |
| 6 | The playback controls navigate through the tracks and set the volume on your Apple device, if it is connected to the console. | | |

The following figure shows how the home screen appears on the console. All eight buttons are active, and the name of each button appears next to it.



Figure 8: Home screen and capacitive buttons

Using the Console Controls 19

Connecting Your Apple Device

The reading tray at the top of your display console can also hold an iPad®, iPhone®, or iPod® device. If you connect your device to the console, you can use the console's headphone connector and playback controls to listen to your audio more conveniently, without risk of dropping your device during your workout. If you have the Preva® mobile app installed on your iPhone, you can also upload the your workout results to your Preva account.

Tip: If you are using a different mobile device that has a USB charging cable, you can charge your device by connecting it to the console. However, the console's playback controls and headphone connector work only with Apple devices.

To connect your device to the display console:

1. Gently open the access cover on the back of the console, as shown in the following figure.



Figure 9: Opening the access cover

2. Feed the USB connector on your device's data and charging cable through the opening in the reading tray.

3. Insert the USB connector into the jack on the back of the console, as shown in the following figure.



Figure 10: USB connector positioning

- 4. Close the access cover.
- 5. Plug the other end of the cable into your device.
- 6. Feed any excess cable through the opening in the reading tray.

Using the Console Controls 21

Setting Up Your Equipment

After the console is installed, it needs the following information to work correctly:

- The model number of the equipment
- The date and time
- Your measurement preferences (kilometers or miles)

You will need to enter this information before you can start to use the equipment. If you need to change it later, you can do so at any time (refer to *Changing the System Settings*).

Note: You can find the model number of your equipment on the sales receipt, invoice, or packing list that you received with the equipment.

To set up the console:

- Turn the equipment on.
- 2. At the Welcome screen, touch Start.




Figure 11: Welcome screen

At the Initialize Your Equipment screen, touch Next. 4. At the Treadmill Model screen, use the up and down arrow buttons to select the model you have, then touch **Next**.



Figure 12: Treadmill Model screen


5. At the Date screen, use the arrow buttons to enter the current date.



When you have finished entering the date, touch **Next**.

Setting Up Your Equipment 23

6. At the Time screen, use the **12 Hour / 24 Hour** button and the arrow buttons to enter the current time.



When you have finished entering the time, touch **Next**.

7. At the Unit Preference screen, use the up and down arrow buttons to select kilometers or miles, then touch **Next**.



Figure 13: Unit selection

8. At the Equipment Settings screen, review the information you have entered.

If ... Then touch ...

All of the information is correct

Save

Some of the information needs to be changed

Back or Edit



Figure 14: Equipment Settings screen

9. Continue according to whether you want to set up the first user profile for this equipment.

| If | Then touch | And |
|--|---------------|---|
| You want to set up a user profile | Next | Set up a profile (refer to Creating User Profiles). |
| You do not want to set up a user profile right now | Skip | Use the equipment as a guest. |

Important: If you do not set up user profiles now, be sure to set them up as quickly as possible. Anyone who uses this equipment regularly will need a user profile to track progress, personal information, and favorite workouts.

Setting Up Your Equipment 25

Measuring Your Heart Rate

Precor cardio equipment can measure your heart rate in one of two ways:

- If you have a chest strap (for use with a fitness watch, for example), the equipment can receive the heart rate signal the strap transmits.
- You can grasp the heart rate sensors on the handlebars.

When the equipment detects your heart rate, the following things happen:

- The heartbeat indicator (icon) begins to flash.
- After a few seconds, the console displays your current heart rate.
- If SmartRate is on, a second heartbeat icon appears over your current heart rate zone (refer to Using SmartRate).

Before you start working out, make sure you know your maximum heart rate. Then, as you work out, be sure to reduce the intensity of your exercise if you reach or exceed that number.

CAUTION: Your heart rate should never exceed 85% of your maximum heart rate.

You can use the following formula, provided by the American College of Sports Medicine[®], to figure out your maximum heart rate:

Maximum heart rate = 207 - (your age × 0.67)

Your typical target heart rate is 70% of your maximum rate.

The following graph shows how your effective heart rate ranges vary with your age.




Figure 15: Heart rate target zones

On the Workout List, you can find several heart rate workouts (refer to *Available Workouts*). These workout courses automatically manage your heart rate at a target level based on your age. By monitoring your heart rate and making changes to the equipment's settings as you exercise, the workouts keep your heart rate within a few beats per minute of the target rate.

Measuring Your Heart Rate 27

Using SmartRate



You must be signed in under your user profile to use this feature.

During your workout, SmartRate® maps your heart rate on a scale of different target zones that show you what kind of conditioning you're getting. These zones are defined as percentages of your maximum heart rate. Your maximum heart rate is based on the following formula:

Heart rate limit in beats per minute = 207 beats per minute - (your age in years × 0.67)

At any time during your workout, your actual heart rate is some percentage of this number. SmartRate uses that percentage to find your current zone. For example, if you were 35 years old and wanted to work out in the suggested cardiovascular zone, your target heart rate would be between 128 and 154 beats per minute.

 $(207-(35 \times 0.67)) \times 70\% = 128$ beats per minute $(207-(35 \times 0.67)) \times 84\% = 154$ beats per minute

The following table shows the percentage ranges for each zone.

Table 2. SmartRate zone boundaries

| Heart Rate Range | SmartRate Zone | |
|-------------------------|---|--|
| Less than 54% of limit | Warm-up | |
| 55%-69% of limit | Moderate (good for weight loss) | |
| 70%-84% of limit | High (good for cardiovascular conditioning) | |
| Above 85% of limit | Maximum | |

CAUTION: Your heart rate should never exceed 85% of your maximum heart rate or go into the Maximum zone. If it does, reduce the intensity of your workout IMMEDIATELY.

If SmartRate is on, you will see a heart rate indicator () over the SmartRate zone bar during your workout. This indicator shows where your current heart rate falls within the active zone. You can then change the intensity of the workout to stay within the zone you want.



Figure 16: SmartRate zone bar

To make sure that SmartRate works correctly, you need to make sure of the following things:

- Your age is properly set in your user profile.
- The equipment can read your heart rate properly. If you are using a chest strap, you must moisten and position it properly. If you are using the touch-sensitive grips on the equipment, you must maintain contact with both grips for five to ten seconds.

Note: SmartRate is on by default, but it is not available if the Guest account is selected.

To turn on SmartRate:

- 1. During your workout, touch **Options**.
- At the Options screen, touch SmartRate On.
- 3. Touch **Back** to return to your workout.

Note: There is only one SmartRate button on the Options screen. If SmartRate is currently on, the button is named **SmartRate Off**. If SmartRate is currently off, the button is named **SmartRate On**.

Measuring Your Heart Rate 29

Getting Accurate Heart Rate Readings

To work reliably, heart rate sensors need to be securely in contact with your skin. Use the following guidelines to make sure they are.

To attach a chest strap:

WARNING Signals used by the chest strap transmitter (or heart rate strap) may interfere with pacemakers or other implanted devices. Contact your doctor, the manufacturer of the chest strap, and the manufacturer of the implanted device before using a chest strap transmitter.

Important: Precor cardio equipment works with 5 KHz chest straps only. It does not work with Bluetooth -based chest straps, which are designed for use with mobile apps. **Note:** To receive an accurate reading, the strap needs to be in direct contact with the skin on the lower sternum (just below the bust line for women).

Carefully dampen the back of the strap with tap water. Refer to the following figure.

Note: Do not use deionized water. It does not have the proper minerals and salts to conduct electrical impulses.



Figure 17: Moisten chest strap

2. Adjust the strap and fasten it around your chest. The strap should feel snug, not restrictive. Refer to the following figure.




Figure 18: Adjust chest strap

 Make sure that the chest strap is right side up, lies horizontally across your chest, and is centered in the middle of your chest. Refer to the following figure.




Figure 19: Fasten chest strap

4. After you put on the chest strap, face the display console for a few seconds. This allows the receiver in the console to recognize the signal from the chest strap.

If you use the touch-sensitive grips, be sure to grasp them securely (but not tightly—use a loose, cupping hold) on both sides. You may need to wait for 15 to 20 seconds before your heart rate is displayed.

Important: The touch-sensitive grips work well for most people. However, because of their body chemistry or erratic heartbeats, a few people cannot use the grips. If this applies to you, a chest strap may provide better results. However, do not grasp the touch-sensitive grips while wearing a chest strap—using both at the same time can cause erratic heart rate readings.

Measuring Your Heart Rate 31

Setting Your Target Heart Rate



You must be signed in under your user profile to use this feature.

Once you have set your target heart rate, some of the built-in workouts can help you stay at that heart rate for your entire exercise session.

Important: You cannot change your target heart rate during a heart rate controlled workout. Also, your heart rate setting is not saved along with your workout.

To set your target heart rate:

- 1. During your workout, touch **Options**.
- 2. At the Options screen, touch Change Target HR.

3. At the Set Target Heart Rate screen, use the up and down arrow buttons to adjust your target heart rate. As the rate changes, the corresponding SmartRate zone for your age appears next to it.



Figure 20: Set Target Heart Rate screen

- 4. When you have finished setting your target heart rate, touch **Save** to register your changes and return to the Options screen.
- 5. Touch **Back** to return to the workout status display.

Troubleshooting Heart Rate Readings

If your heart rate readings look wrong, or if you do not see any readings at all, check the following list for possible causes. If the solutions in this list do not solve the problem, contact your dealer or Precor Customer Support.

No Heartbeat Icon or Heart Rate Display The heart rate sensors may not be in secure contact with your skin. Try the following solutions.

For touch-sensitive grips:

- Make sure that your hands grasp the touch-sensitive grips continuously and firmly (but not tightly) for at least five to ten seconds.
- Check that the palms of your hands are not covered with any sort of salve, rub, or lotion. If they are, wash them.
- Check that your hands are not too dry. If they are, moisten them slightly.

For a chest strap:

- Make sure the strap is fastened, positioned, and moistened correctly.
- Make sure the strap is compatible with the equipment. It must be a 5 kHz strap. Heart rate straps that function at other frequencies, and Bluetooth-based straps, are not compatible with this equipment.

The Displayed Heart Rate Is Wrong Or SmartRate Doesn't Work

The touch-sensitive grips may not be making secure contact. Try the following solutions:

- Make sure that your hands are clean, slightly moist, and positioned as described earlier in this table.
- Try using a chest strap instead of the grips.

If you are trying to use the grips and an active chest strap at the same time, choose one or the other. Either do not grasp the touch-sensitive grips, or remove or turn off the chest strap.

Measuring Your Heart Rate 33

Choosing and Completing a Workout

The instructions shown earlier in this manual (refer to *Getting Started*) provide the simplest possible steps for getting started with your new fitness equipment. In most cases, you'll want to start with one of the preprogrammed workouts available on the equipment. This chapter explains how to select a workout and describes the changes you can make as it progresses.

Note: If you're signed in under your user profile, you can save your completed workout as a personal favorite and use it again later (refer to *Finishing Your Workout*). If you've made any adjustments to the intensity of the workout, your changes will be stored as well.

The human body is extremely efficient. If it makes the same motion regularly over many days or weeks, it learns to make that motion with less and less effort. This process, called *muscle adaptation*, has one drawback—the longer you stick to the same workout, the less good that workout does you.

To prevent muscle adaptation from setting in as you work out, try different kinds of workouts on different days. By keeping your muscles guessing, you'll keep your energy use up, promoting faster weight loss and better conditioning.

The workouts on your Precor fitness equipment are organized by goal. Under each goal there are workouts of different types, which provide different benefits:

- Interval workouts help exercisers improve strength, endurance, aerobic fitness, and anaerobic fitness. They alternate between stages of higher and lower intensity called work stages and rest stages. During the rest stages, your metabolic and heart rates slow down. Meanwhile, your body takes in and distributes more oxygen for the next work stage. Over time this pattern keeps your calorie use up, promoting weight loss, improved aerobic response, and increased overall stamina. To improve your general fitness over time, start with a 1-1 interval workout, then progress to the 2-1 workout, then the 4-1 workout. To enhance your peak performance, choose a 1-2 or 1-4 workout and set a challenging level for the work stages.
- Aerobic workouts are designed to keep your oxygen consumption as high as possible, which improves your fitness over time. Benefits of aerobic conditioning include greater heart and lung capacity, stress management, and an overall sense of vitality.

- Weight loss workouts are designed to maintain a steady-state, lower-intensity level of exercise, keeping you in a workout zone that burns a higher amount of fat calories.
- Toning and sculpting workouts focus on improving the shape and definition of specific groups of muscles.
- Terrain workouts simulate an outdoor run, walk, or climb.
- Distance workouts simulate popular distance runs.
- Heart rate controlled workouts hold you at an optimal heart rate for your training goal by adjusting intensity to keep you at a fixed exertion level.
- The **fitness test** is a multi-stage test of increasing intensity used to predict your maximum aerobic capacity and estimate your current fitness level.

Tip: If you are signed in under your user profile, you can adjust most workouts and save them as favorites. The adjustments in your saved workout can be as frequent as every 15 seconds. For example, to create a high-intensity interval training (HIIT) workout, you can make your work stages as short as 15 seconds.

Choosing a Workout

When you start your workout, the following options are available on the home screen:

- QuickStart (begin a manually defined workout)
- My Workouts (use a favorite workout that you have saved)
- Go (use a workout suggested by the equipment)
- Workout list (select from a list of predefined workouts)

The following sections describe each of these options.

Choosing QuickStart

The QuickStart option allows you to get moving as quickly as possible—just touch **QuickStart** and start exercising. This workout is manually controlled and starts out with the intensity settings at their lowest levels. Simply adjust the settings to produce the workout profile you want.

Tip: You can use QuickStart to design and save a workout of your own (refer to *Finishing Your Workout*). Touch **My Workouts** to use the saved workout again later.

Repeating a Saved Favorite Workout



You must be signed in under your user profile to use this feature.

In addition to the workouts that come with the equipment, you can create your own favorite workouts and save them for use again later. The equipment also remembers your last four workouts whether you save them or not. To use a recent or saved workout again, touch **My Workouts** (refer to *Finishing Your Workout*).



Figure 21: My Workouts button

Using the Suggested Workout

The equipment always displays a suggested workout when you first turn it on. If you are signed in under your user profile, the equipment suggests a workout that will help you concentrate on your primary focus. To start the suggested workout, simply touch **Go**.



Figure 22: Go button

Selecting a Workout from the Workout List

Your fitness equipment has been programmed with a library of workout plans designed to help you meet your fitness goals. The workouts are arranged by goal:

- Be Fit
- Lose Weight
- Push Performance
- Get Toned
- **Go the Distance** (complete a distance run, such as one mile or 5K)
- Fitness Test

Note: You choose one of the first four as your primary focus when you create your user profile (refer to *Creating User Profiles*). After that, your focus is highlighted in the workout list, and the workout assigned to the **Go** button is always a workout associated with that focus. However, you can always choose any workout, no matter what your primary focus is.

To select a workout:

At the home screen, touch Workouts.



Figure 23: Workouts button

2. Use the up and down arrow buttons to select a focus.

3. Touch **Open** to show the workouts available for that focus. (Touch **Close** to hide them again.)



Figure 24: Workout type selection

4. Use the up and down arrow buttons to highlight the workout you want, then touch **Start**.




Figure 25: Workout selection

Available Workouts

Your fitness equipment includes a wide selection of workouts that are carefully designed to make sure you get the best results out of every workout.

The training parameters for these workouts vary according to their training goals. In this chapter, the following symbols describe how each workout varies its intensity and how you can modify it:



The workout changes this type of intensity automatically.



You can manually adjust the changes that the workout makes.

Be Fit

| Workout | Profile | Incline | Speed | |
|---|---------|----------------|----------------|--|
| 1–1 Interval: Cycles of two minutes of intense exercise and two minutes of rest. | ШШШ | a 8 | 4 2 | |
| 2-1 Interval: Cycles of two minutes of intense exercise and one minute of rest. | шш | a B | a a a a | |
| 4-1 Interval: Cycles of four minutes of intense exercise and one minute of rest. | | a a a a | a a a a | |

| Workout | Profile | Incline | Speed |
|--|---------|------------|-------|
| Rolling Hills: A simulated run over gradually steeper hills. | - | 4 2 | 8 |
| Mountain Peaks: A simulation of a two-summit climb. (No climbing gear required!) | Auk | 3 | 8 |
| Heart Rate Cardio: Work and rest cycles managed by the equipment to keep your heart rate at the best level for moderate cardiovascular conditioning. | | • | 8 |

Lose Weight

| Workout | Profile | Incline | Speed |
|---|---------|------------|------------|
| 4-3 Interval: Cycles of four minutes of work and three minutes of rest. | | a B | a B |
| Aerobic: Workout routine designed to challenge and improve your aerobic fitness. | *** | 8 | 8 |
| Aerobic Plus: More intense version of the Aerobic workout. | 4444 | a B | 8 |

| Workout | Profile | Incline | Speed |
|--|---------|------------|----------|
| Fat Burner: Calorie-burning routine with cycles of gradually increasing resistance. | AA | a B | 8 |
| Heart Rate Fat Burn: Workout managed by the equipment to keep your heart rate at the most effective level for weight loss (moderate intensity, but with a high-intensity stage in the middle). | | ••• | 8 |

Push Performance

| Workout | Profile | Incline | Speed |
|--|---------|--------------|----------------|
| 1-4 Interval: Cycles of one minute of intense exercise and four minutes of rest. | тт | a a a | a a a a |
| 1-2 Interval: Cycles of one minute of intense exercise and two minutes of rest. | шш | 4 2 | a B |
| Heart Rate Zone: Quick bursts of intense exercise, managed by the equipment to keep your heart rate at a high performance level. | | • | 8 |

Get Toned

| Workout | Profile | Incline | Speed |
|--|---------|--------------|-------|
| Glute Toner: Gradually increasing incline with an abrupt drop-off, designed to improve the shape of your thighs and gluteal muscles. | | a | 8 |
| Glute Toner Plus: More intense workout targeting your thighs and gluteal muscles. | | 4 2 | 8 |
| Leg Sculpt: Cycles of increasing intensity designed to define and strengthen your leg muscles. | | a | 8 |
| Leg Sculpt Plus: More intense version of the Leg Sculpt workout. | | a a a | 8 |

Go the Distance

This group of workouts allows you to set your preferred intensity levels and pace for one of the following distances:

- 1 Mile
- 5K
- 10K

Note: During these workouts, the equipment does not modify workout intensity in any way.

Fitness Test

This test is a modified version of a widely-used fitness test. After a three-minute warm-up, you will complete a series of test stages of increasing intensity. (Speed and incline increase in alternating stages.)

Important: After the warm-up stage of the test, you cannot adjust the speed or incline settings.

The treadmill ends the test prematurely if either of the following things happen:

- The treadmill cannot detect your heartbeat.
- Your heart rate exceeds 85% of your maximum safe rate for 15 seconds or more.
- Your heart rate changes too quickly.
- You press the STOP switch or remove the stop key.

After you complete the test, the treadmill displays your score. The score number shows the maximum amount of oxygen your body can take in over a period of time, in milliliters per kilogram of body weight per second (abbreviated as VO_2 max).

Important: For best results, sit and rest for at least five minutes before you take the test. Do not hold on to the handrails during the test, or your final score may be inaccurately high.

To see how your performance level increases with exercise over time, try taking the fitness test as soon as possible after you install the equipment. Then, as you keep working out, take the fitness test from time to time and watch your results improve.

Refer to the following two tables to compare your fitness level to typical levels for your age and gender.

Table 3. Cardio-Respiratory Fitness Score Category (Women)*

| | Fitness Category | | |
|-----------------|------------------|-------------------|-----------------|
| Age in Years | Low Fitness | Medium Fitness | High Fitness |
| 20-39 | 28 or below | 28-34 | 34 or above |
| 40-49 | 26 or below | 26-32 | 32 or above |
| 50-59 | 24 or below | 24-29 | 29 or above |
| 60 or over | 22 or below | 22-27 | 27 or above |

Table 4. Cardio-Respiratory Fitness Score Category (Men)*

| | Fitness Category | | |
|-----------------|------------------|-------------------|-----------------|
| Age in Years | Low Fitness | Medium Fitness | High Fitness |
| 20-39 | 35 or below | 35-43 | 43 or above |
| 40-49 | 32 or below | 32-40 | 40 or above |
| 50-59 | 29 or below | 29-37 | 37 or above |
| 60 or over | 24 or below | 24-32 | 32 or above |

^{*} The test and analysis algorithm were developed by Dr. Neil Gordon of The Cooper Clinic.

Changing Settings and Metrics While You Work Out

When you start a workout, you select a pre-defined program. However, in addition to changing the intensity of the workout, you can change many of its other aspects. You can also adjust the workout progress graph so that it displays the information you want to see.

You can make the following changes at any time:

- Workout selection (between workouts that can be interrupted)
- Workout length
- Information displayed on progress graph
- Metrics displayed on screen
- Metrics Scan (all available metrics appear in sequence on the screen)

In addition, if you are signed in under your user profile, you can change the following:

- Target heart rate (except for heart rate controlled workouts)
- SmartRate activation / deactivation

Changing Your Workout Length

The normal length of your workout (the *default duration*) is preset to 30 minutes. If you want to choose a different amount of time, you can do that after you have started your workout.

To change the length of your current workout:

1. At the main workout screen, touch **Change Time**.



Figure 26: Change Time button

2. Use the up and down arrow buttons to increase or decrease the length of your workout.



Figure 27: Change Duration screen

Touch Save to return to the main workout screen.
 Note: Touching Back instead of Save returns you to your workout without saving the changes.

Changing the Workout Display

While you are working out, you can choose different measurements of your progress, or *metrics*, as shown in the following figure and table. Simply touch the button next to the measurement you want to change.

Note: If you are signed in under your user profile, the equipment will save your display settings and metrics selections for the next workout, even if you don't save your workout.




Figure 28: Time measurement selection

Table 5. Workout metrics

| Metric | Types Available |
|-----------------|--|
| Workout Time | Time Elapsed (the amount of time you've been exercising during this workout) |
| | Time Remaining (the amount of time left in the workout) |
| | Finish Time (for workouts whose total distance is defined) |
| | Segment Time (time remaining in the current intensity segment of the workout) |
| Achievement | · Total Distance |
| | Distance Remaining (for workouts whose total distance is defined) |
| | • Elevation Gain (total for this workout) |

| Metric | Ту | pes Available |
|------------|----|--|
| Speed | • | Pace (amount of time required to complete one mile or kilometer, based on your current speed) |
| | • | Average Pace (based on the entire workout so far) |
| | | Average Speed |
| Energy Use | • | Calories (total for this workout) |
| | • | Calories / Min (calories per minute) |
| | • | Calories / Hr (calories per hour) |
| | • | METs (metabolic equivalents)* |
| | • | Watts |

| Metric | Types Available |
|------------|--|
| Heart Rate | • Current HR (current heart rate) |
| | • Current Zone (current SmartRate zone: warm-up, moderate, high, or maximum) |
| | Average HR (average heart rate in this workout) |
| | Max HR (maximum heart rate in this workout) |
| | • Target HR (target heart rate) 6 |
| | • Time in Zone (time elapsed in the current zone, moderate and high zones only) |

* You can think of one MET as the amount of energy you use while sitting still, based on your body weight. If you're working out at three METs, that's three times the energy you would use if you weren't moving. Some personal trainers and medical professionals suggest tracking METs instead of calories because your MET target doesn't change as your weight changes.

If you want to see all of this information during your workout, you can turn on Metrics Scan. While Metrics Scan is on, each metric changes every three seconds to show all of the types of information it can display.

To turn on Metrics Scan:

- During your workout, touch Options.
- 2. At the Options screen, touch **Turn On Metrics Scan**.

Note: to turn off Metrics Scan, repeat the preceding steps. The **Turn On Metrics Scan** button is renamed **Turn Off Metrics Scan** if this feature is active.

You can also change the information shown in the progress graph during your workout.

To change the progress graph:

- 1. During your workout, touch **Options**.
- 2. At the Options screen, touch Change Graph.
- 3. Use the arrow buttons to move between the types of information you can display on the graph (speed, incline, or heart rate). Touch **Add** or **Remove** to select one or two types of information.




Figure 29: Change Graph Preferences screen

4. Touch **Save** to save your changes and return to the workout progress graph. The types of information you selected appears as lines in the graph.



Figure 30: Progress graph with heart rate and speed lines

Note: The bars in the progress graph can describe incline, speed, or a combination of both (refer to *Available Workouts*). The width of each bar corresponds to one minute for timed workouts, or 200 meters (656 feet) for distance-controlled workouts. These bars scroll from right to left as your workout continues. The line above the bars shows the entire length of your workout and your current position in it.

Changing Your Mind During Your Workout

As your workout continues, you might find that you'd rather be doing a different workout than the one you originally selected. If so, you can switch from one workout to another without stopping. The actual results of your combined workout will be saved in your profile, and you can save the mixed workout to use it again later (refer to Finishing Your Workout).

Note: You can't change to a heart rate workout or a fitness test, and you can't change from a fitness test to another workout.

To change a workout in progress:

- Touch Options.
- 2. On the Options screen, touch **Change Workout**.
- Select a new workout from the workout list, then touch **Start**.

Note: If you want to use one of the workouts you have completed recently, touch **Recent Workouts**. Use the up and down arrow buttons to select the workout you want, then touch **Start**.

Finishing Your Workout

If you need to end your workout early, simply touch **Pause**, then **Finish**. You will see a summary of what you have accomplished during the workout. All of the metrics around the edges of the screen show your totals and averages for the entire workout, and the progress graph remains in the center of the screen.

Tip: You can also end your workout at any time by pressing the STOP switch twice.

If you finish the workout normally, you go through a short, less intense cooldown stage after the workout itself. This additional stage brings your heart rate down in a gradual, controlled manner and helps prevent stiff, sore muscles later. After the cooldown stage, the Workout Summary screen appears. You can see the effect of the cooldown stage by touching **View with Cool Down** and **View Workout Only**.




Figure 31: Workout Summary screen and View With Cool Down button

Saving Your Workout



You must be signed in under your user profile to use this feature.

At the workout summary screen, you can save the workout you've just finished so you can use it again later. Your saved workout includes any intensity changes you make that last longer than 15 seconds, as well as the actual total time.

Note: You can save your workout only if it lasted five minutes or more. You cannot save your workout under any of the following conditions:

- You worked out for less than five minutes.
- You have changed between a distance workout (such as a 10K run) and a timed workout, in either direction.
- You were using a heart rate controlled workout or taking a fitness test. (You can't store your current heart rate or fitness level.)

To save your workout:

Touch Save Workout.



Figure 32: Save Workout button

2. At the Name Your Workout screen, use the Shift and arrow buttons to enter a name for this workout.

Scroll between letters, numbers, and spaces (use the Shift button to switch between upper and lower case)



Note: If you prefer not to name the workout, you can also leave the default name of "Favorite number", where number is a single digit.

3. When you have finished specifying the name, touch **Save**.

To use a saved workout again:

- 1. If necessary, switch to your own user profile (refer to *Choosing a User Profile*).
- 2. At the home screen, touch My Workouts.
 - **Note:** Your saved workouts are listed in the order in which you last used them, with the most recent workout first.
- 3. Use the up and down arrow buttons to select a workout, then touch **Start**.

Note: The duration and total distance of a saved workout cannot be changed.

Checking Your Weekly Progress



You must be signed in under your user profile to use this feature.

To see how much progress you've made each week, touch the **My Stats** button on the home screen. This button takes you to the My Stats screen, where you can see the following weekly totals:

- Workouts completed
- Distance covered
- Time (hours and minutes) completed
- Calories burned



Figure 33: My Stats screen

Touch **Home** to return to the home screen.

To track your progress over more than one week, and to coordinate your workouts on this equipment with your other forms of exercise, connect to Preva before each workout (refer to *Tracking Your Progress with Preva*). Using Preva, you can manage all of your exercise toward a single weekly goal and track your lifetime progress as well.

Note: Each week starts on Monday and ends on Sunday.

Tracking Your Progress with Preva

Preva is a free, cloud-based service from Precor that tracks all of your exercise—at home, at the gym, or outdoors—to help you stay focused on your fitness goals. Through your iPhone device and Preva-equipped Precor fitness equipment, Preva tracks all of your workouts and lets you know whether you're on track, ahead, or behind your goals. It also helps you celebrate major milestones in your progress (including some with actual miles or kilometers) and keeps your workout history.

To make sure Preva follows the progress you make on your new fitness equipment:

- 1. If necessary, download the free Preva app from iTunes® or the Apple App StoreSM.
- 2. Make sure that you are signed in to Preva.
- At any time before you finish your workout, connect your iPhone to your equipment.
 - **Note:** before you begin your workout, you will need to connect your iPhone data cable to the console (refer to *Connecting Your Apple Device*).
- 4. Check to make sure that the playback controls appear on the console, indicating that your iPhone is properly connected.

At the end of the workout, your workout information is uploaded automatically to your Preva account. Your Goal Compass™ and your workout history are updated to include this workout.

Creating User Profiles

When you first create your user profile, you start by storing your personal information (age, weight, gender, and workout focus). As you continue working out with the equipment, it stores your progress and your workout preferences. In other words, your user profile allows the equipment to fine-tune itself to your needs.

Your user profile allows you to do the following things:

- Use SmartRate, or set your target heart rate, to help ensure you get the cardiovascular workout you want
- Receive workout suggestions based on your own fitness focus
- Save favorite workouts and use them again later
- Set your own default workout duration and display settings
- Automatically see accurate calorie use estimates based on your age
- Track your progress throughout the week

Note: Some features of the equipment are available only if you are signed in under your user profile. Those features are identified with a user profile symbol (3) in this guide.

Creating User Profiles 59

The equipment can store profiles for up to four people. Each profile has a unique color and a unique name—you can enter your own name or leave the "User number" name that the equipment first assigns to your profile. When you select your profile later, the equipment addresses you by name and all of the screens are accented in your color.

You can change your profile information by touching the **My Profile** button at the home screen.




Figure 34: Home screens for all user profiles

Note: In addition to the four user profiles, a Guest profile is always available. While you use the Guest profile, the equipment does not store settings, results, or workouts.

To create a profile:

- At the home screen, touch Change User.
- 2. On the user list screen, the buttons on the right show the names of user profiles that have already been created. The first available button is labeled **Add User**. Touch this button to continue.

Note: If no **Add User** button appears, the equipment already has as many user profiles as it can store. In this case, if you want to create an additional profile, you must either edit one of the existing profiles or delete it (refer to *Deleting User Profiles*).


3. On the User Name screen, use the arrow and **Shift** buttons to enter your name.

Scroll between letters, numbers, and spaces (use the Shift button to switch between upper and lower case)



Touch **Next** to continue.

4. On the Enter Weight screen, use the arrow buttons to enter your current weight.



Touch **Next** to continue.

Creating User Profiles 61

- On the Select Gender screen, use the up and down arrow buttons to confirm your gender, then touch Next.
- 6. On the Enter Date of Birth screen, use the arrow buttons to enter the date when you were born.

Increase or decrease (hold to scroll faster)



When you have finished entering your birthdate, touch **Next**.

- 7. On the Select Focus screen, use the up and down arrow buttons to select your workout focus:
 - **Be Fit** (maintain a healthy lifestyle)
 - Lose Weight
 - Push Performance (challenge and improve your stamina)
 - **Get Toned** (improve your muscle tone)

Touch **Next** to continue.

8. On the My Profile screen, review the information you have entered.

If ... Then touch

...

All of the information is correct **Save**

Some of the information needs to be changed Back or Edit

As you lose weight, or if you want to change any of your other profile information, you can make your changes easily. Just touch **My Profile** at the home screen. Your profile is then displayed and you can choose individual parts of your profile to change.

Choosing a User Profile

Your fitness equipment can store user profiles for up to four different people. Each person is represented by a different color. Also, a Guest profile is available. Your visitors can choose the Guest profile if they want to use the equipment, but it will not store their results.

Note: SmartRate[®] is not available when the Guest profile is selected.

To choose a user profile:

- 1. At the home screen, touch **Change User**.
- 2. On the user list screen, touch one of the buttons on the right side of the screen.




Figure 35: User profiles

Note: The user profile you have selected remains active until someone chooses a different profile.

Creating User Profiles 63

Changing Your Default Settings



You must be signed in under your user profile to use this feature.

In addition to the overall settings for the fitness equipment, you can adjust the following settings for your specific profile.

Table 6. User profile treadmill settings

| Setting | Default value |
|--------------------------|-------------------|
| Default workout duration | 30 minutes |
| Maximum speed | 12 mph (19.3 kph) |

To change your user settings:

- 1. At the home screen, touch **Settings**.
- 2. At the Settings screen, touch **My Settings**.
- 3. Use the up and down arrow buttons to select a setting to change, then touch **Edit**.
- 4. Use the up and down arrow buttons to make your adjustment, then touch **Save** to return to the My Settings screen.
- 5. If necessary, repeat the previous two steps to adjust the other setting.

Deleting User Profiles

You have to select a profile before you can delete it. This helps prevent people from accidentally deleting each other's profiles.

To delete a user profile:

- At the home screen, touch Change User.
- 2. Using the buttons on the right of the screen, select the user profile you want to delete.
- After you return to the home screen, touch My Profile.
- 4. On the My Profile screen, touch **Delete Profile**.
- 5. On the Delete Profile screen, use the up and down arrow buttons to select **Yes**, then touch **Delete**.

Creating User Profiles 65

Changing the System Settings

When you first set up your equipment, you entered the following information:

- Equipment model number
- Date
- Time
- Units of distance (kilometers or miles)

If you need to change these settings, touch the **Settings** button at the home screen.

Note: These settings affect all users. For example, if you set the distance units to kilometers, everyone sees their workout distances in kilometers.

To correct the model number:

- At the Settings screen, use the up and down arrow buttons to select **Model**, then touch **Edit**.
- 2. At the Set Model screen, use the up and down arrow buttons to select the model you have, then touch **Save**.

To change the date:

- 1. At the Settings screen, use the up and down arrow buttons to select **Date**, then touch **Edit**.
- 2. At the Set Date screen, use the arrow buttons to enter the current date.

(hold to scroll faster)


Increase or decrease



When you have finished entering the date, touch **Save**.

To change the time:

- 1. At the Settings screen, use the up and down arrow buttons to select **Time**, then touch **Edit**.
- 2. At the Set Time screen, use the **12 Hour / 24 Hour** button and the arrow buttons to enter the current time.



When you have finished entering the time, touch **Save**.

To switch between kilometers and miles:

- At the Settings screen, use the up and down arrow buttons to select **Distance Units**, then touch **Edit**.
- 2. At the Set Unit Preference screen, use the up and down arrow buttons to select kilometers or miles, then touch **Save**.

Changing the System Settings 67

Retrieving System Information

If you ever need to contact your dealer or Precor Customer Service for help, you may be asked to check the equipment's system information and error log.

The following technical information about your equipment is available for reference:

- Software release part number
- Software version numbers
- Hardware version and serial numbers (console)
- LPCA (equipment base unit control circuit) version number
- Total equipment usage (in hours and minutes)
- Odometer (total usage in kilometers or miles)

To view the system information:

- 1. At the home screen, touch **Settings**.
- At the Settings screen, touch Information.



Figure 36: Information screen (example)

3. When you are finished viewing the system information, touch **Home**.

Displaying the Error Log

Each entry in the error log includes the following information:

- An error ID number
- An error code
- Data providing details about the error
- The time and date when the error occurred
- The odometer setting when the error occurred

To display the error log:

- 1. At the home screen, touch **Settings**.
- 2. At the Settings screen, touch **Information**.
- 3. At the Information screen, touch Error Log.




Figure 37: Error log

4. When you are finished viewing the error log, touch **Home**.

Changing the System Settings 69

Maintenance

It is important to perform the minor maintenance tasks described in this section. Failure to maintain the equipment as described here could void the Precor Limited Warranty.

DANGER To reduce the risk of electrical shock, always unplug the equipment from its power source before cleaning it or performing any maintenance tasks.

Inspection

Inspect the treadmill daily.

- Look and listen for slipping belts, loose fasteners, unusual noises, worn or frayed power cords, and any other indications that the equipment may be in need of service. If you notice any of these, obtain service.
 - **Important:** If you determine that the treadmill needs service, make sure that the treadmill cannot be used inadvertently. Turn the unit Off, and then unplug the power cord from its power source. Make sure other users know that the treadmill needs service.
- 2. Check for worn, frayed or missing safety lanyards. Replace missing or worn safety lanyards immediately. Do not exercise on the treadmill without attaching the safety clip to your clothing.

To order parts or to contact a Precor authorized service provider in your area, refer to Obtaining Service.

Cleaning the Equipment

Most of the working mechanisms are protected inside the hood and base of the treadmill. However, for efficient operation, the treadmill relies on low friction. To keep the friction low, the unit's running belt, staging platforms, and internal mechanisms must be as clean as possible.

Precor recommends the treadmill be cleaned before and after each workout to remove dust, dirt, water, and sweat. Use mild soap and water to dampen a soft cloth and wipe all exposed surfaces.

CAUTION: Do not use any acidic cleaners. Doing so will weaken the paint or powder coatings and void the Precor Limited Warranty. Never pour water or spray liquids on any part of the treadmill, and remove any accumulated sweat from the treadmill after use. Allow the treadmill to dry completely before using it again.

Frequently vacuum the floor underneath the unit to prevent the accumulation of dust and dirt, which can affect the smooth operation of the unit. Use a soft nylon scrub brush to clean the running belt.

Storing the Chest Strap

Store your chest strap in a place where it remains free of dust, dirt, and moisture, such as in a closet or drawer. Be sure to protect the chest strap from extremes in temperature. Do not store it in a place that may be exposed to temperatures below 32° F (0° C).

To clean the chest strap, use a sponge or soft cloth dampened in mild soap and water. Dry the surface thoroughly with a clean towel.

Maintenance 71

Checking the Alignment of the Running Belt

Proper belt alignment allows the belt to remain centered and ensures smooth operation. Realigning the belt takes a few simple adjustments. If you are unsure about this procedure, call Precor Customer Support.

CAUTION: Special care must be taken when aligning the running belt. Turn off the treadmill while adjusting or working near the rear roller. Remove any loose clothing and tie back your hair. Be very careful to keep your fingers and any other object clear of the belt and rollers, especially in front of the roller and behind the deck. The treadmill will not stop immediately if an object becomes caught in the belt or rollers.

To check the alignment of the running belt:

- 1. The treadmill has adjustable rear feet. Make sure that the running surface is level. If the treadmill is placed on an uneven surface, adjusting the rear feet can help, but will not compensate for extremely uneven surfaces.
- 2. Turn the unit on.
- 3. Stand beside the treadmill and touch **QuickStart**. The running belt starts automatically after a 3-second countdown appears on the display.
- 4. After the running belt starts, increase the speed to 3 mph (5 kph).

CAUTION: If you hear any chafing or the running belt appears to be getting damaged, stop the running belt immediately by pressing the STOP switch.

NEVER add any foreign substance to the underside of the running belt. The belt is designed to move over the treadmill deck without any additional lubrication. If you notice excessive friction or wear in the running belt, contact Precor Customer Support. 5. Walk around to the rear of the unit and observe the belt for a few minutes. The belt should be centered on the running belt. If the belt drifts off center, you must make adjustments (refer to Adjusting the Running Belt).

Important: Failure to align the belt may cause the belt to tear or fray, which is not covered by the Precor Limited Warranty.

- 6. To stop the running belt, press the STOP switch.
- 7. Turn the treadmill off.

Adjusting the Running Belt

If you are unsure about adjusting the running belt, call Precor Customer Support. Refer to *Obtaining Service*.

CAUTION: For your safety, use the power switch to turn Off the treadmill before making any adjustments. Do not adjust the running belt when someone is standing on the unit.

To adjust the running belt:

1. Locate the right belt adjustment bolt in the rear end cap of the treadmill. Refer to the following figure.




Figure 38: Location of the adjustment bolt

Maintenance 73

To determine left and right, stand at the rear of the treadmill and face the display. Make all belt adjustments on the right rear corner bolt using the hex key provided.

- If the belt is off center to the LEFT, turn the adjusting bolt ¼ turn counterclockwise, which moves the running belt to the right.
- If the belt tracks off center to the RIGHT, turn the bolt ¼ turn clockwise; this moves the belt to the left.

Important: Do not turn the adjusting bolt more than ¼ turn at a time. Overtightening the bolt can damage the treadmill.

2. Recheck the alignment of the running belt.

Long-Term Storage

When the equipment is not in use for any length of time, turn it off. Make sure that the power cord is unplugged from its power source and is positioned so that it will not become damaged or interfere with people, furniture, or other equipment.

Notes:

Notes 75

Notes:

TRM 445 / TRM 243 Low Impact Treadmills

Product Specifications

| roduct Specifications | | |
|-----------------------|-----------------------------------|-----------------------------------|
| | TRM 445 | TRM 243 |
| Length: | 79 in (204 cm) | 81 in (206 cm) |
| Width: | 34 in (86 cm) | 33 in (82 cm) |
| Height: | 59.5 in (151 cm) | 60 in (150 in) |
| Weight: | 358 lb (163 kg) | 238 lb (108 kg) |
| Running Surface: | 22 in × 56 in (56 cm × 142 cm) | 20 in × 57 in (51 cm × 145 cm) |
| Motor: | 3.0 hp continuous duty | |
| Power Requirements: | 120 VAC, 60 Hz | |
| Speed Range: | 0.5-12 mph (0-20 kph) | |
| Incline Range: | -2%-15% grade | 0%-15% grade |
| Frame: | Powder-coated steel | |
| Regulatory Approvals: | FCC, ETL | |

Product Features

| Ground Effects™ | Saved Custom Workouts |
|-------------------------------------|---|
| Integrated Footplant Technology® | Heart Rate Telemetry (chest strap) |
| Capacitive Touch Display | Heart Rate Touch Sensors |
| QuickStart™ | Apple® Compatible Full Audio Control |
| SmartRate® | USB Device Charging |
| User Profiles (4, plus Guest) | USB Software Upgrades |

Workouts

| Be Fit | 1-1 Interval |
|--------------------------|----------------------|
| Deric | |
| | 2-1 Interval |
| | 4-1 Interval |
| | Rolling Hills |
| | Mountain Peaks |
| | Heart Rate Cardio* |
| Lose Weight | 4-3 Interval |
| | Aerobic |
| | Aerobic Plus |
| | Fat Burner |
| | Heart Rate Fat Burn* |
| Push Performance | 1-4 Interval |
| | 1-2 Interval |
| | Heart Rate Zone* |
| Get Toned | Glute Toner |
| | Glute Toner Plus |
| | Leg Sculpt |
| | Leg Sculpt Plus |
| Go the Distance | 1 Mile |
| | 5K |
| | 10K |
| Test Your Fitness | Fitness Test |
| QuickStart | Manual |

Metrics Available

| Metrics Available | |
|--------------------------------------|----------------------------------|
| Speed | Calories per minute |
| Speed (average) | Calories per hour |
| Speed (graph) | METs |
| Pace | Watts |
| Pace (average) | Workout Profile |
| Incline | Workout Selected |
| Incline (graph) | Workout Percentage Complete |
| Elevation Gain | Total Distance |
| Heart Rate (current)* | Distance Remaining |
| Heart Rate (average)* | Time Elapsed |
| Heart Rate (maximum)* | Time Remaining |
| Heart Rate (target)* | Time Remaining (current segment) |
| Heart Rate (graph)* | Finish Time |
| SmartRate* | Units |
| Current heart rate zone | Fitness Test Score |
| Time spent in target heart rate zone | Current User |
| Calories (total) | Current Media Track [†] |

^{*} Use of touch-sensitive heart rate grips or chest strap is required.

[†]An Apple device is required.



Precor Incorporated 20031142nd Ave NE P.O. Box 7202 Woodinville, WA USA 98072-4002 1-800-347-4404 Precor is a registered trademark of Precor Incorporated.

Apple, iPad, iPhone, iPod, and iTunes are registered trademarks of Apple Inc.
Copyright 2014 Precor Incorporated.

Specifications subject to change without notice.

www.precor.com

NOTICE:

Precor is widely recognized for its innovative, award winning designs of exercise equipment. Precor aggressively seeks U.S. and foreign patents for both the mechanical construction and the visual aspects of its product design. Any party contemplating the use of Precor product designs is hereby forewarned that Precor considers the unauthorized appropriation of its proprietary rights to be a very serious matter. Precor will vigorously pursue all unauthorized appropriation of its proprietary rights.



TRM 445 / 243 Owner's Manual 303117-112 rev C, en September 2014





Assembly Guide

PRECISION SERIES TREADMILLS MODELS: 445, 425

Table of Contents

| Getting Started | |
|--|--------|
| Installation Requirements | |
| Unpacking the Equipment | |
| Obtaining Service | |
| Required Tools | |
| Hardware Kit (not to scale) | |
| Assembling the Equipment | |
| Assembling the Frame | |
| Attaching the Handrail Assembly | |
| Attaching the Console to the Treadmill | |
| Attaching the Cables to the Console | |
| Attaching the Dash Buckets | |
| Replacing the Hood | |
| | |
| Completing Assembly | |
| Attaching the Stop Key | |
| Removing the Protective Film | |
| Leveling the Treadmill | |
| | 1 |
| Checking the Alignment | 1 |
| | 1 1 |

2 **TRM 400 Series Assembly Guide**

Getting Started

Thank you for choosing Precor. For proper installation, please read this guide thoroughly and follow the assembly instructions. If you do not assemble the treadmill according to these guidelines, you can void the Precor Limited Warranty.

Installation Requirements

CAUTION: You will need assistance to assemble this unit. DO NOT attempt assembly by yourself.

Follow these installation requirements when assembling the unit:

Assemble the unit near the location where you plan to use it and provide ample space around the unit.

Important: Consult your owner's manual for proper placement of your equipment.

- Make sure that the power switch is OFF and that the treadmill is not plugged into a power source. Check the ON/OFF power switch on the front of the treadmill. Place the switch in the O (OFF) position.
- Assemble the treadmill on a solid, flat surface, A smooth, flat surface under the treadmill helps keep it level and a level treadmill will have fewer malfunctions.
- Open the box and assemble the components in the sequence presented in this guide. If you plan to move the unit, obtain help and use proper lifting techniques.

Important: Grasp the rear end of the treadmill frame or either side of the base frame. Lift the treadmill and roll it on its front wheels. Do not grasp any other plastic part while lifting or moving the unit. The plastic parts are not reinforced and they may break.

- Obtain assistance. Ask another capable adult for assistance during the assembly process.
- Use your fingers or the appropriate tools to insert fasteners. Proper alignment helps prevent crossthreading. Do not fully wrench tighten fasteners until instructed to do so.

Unpacking the Equipment

The treadmill is carefully tested and inspected before shipment. The unit is shipped in two boxes. Ask for help from one or more people to unpack and assemble the treadmill. If any items are missing, please contact your dealer.

WARNING Do not attempt to move the equipment by yourself. Have at least one other person help you and use proper lifting techniques.

To unpack the equipment:

- 1. Carefully cut and remove all plastic straps that secure the cover on the cardboard box.
- 2. Lift the cover upward and set it aside.
- 3. Pull the cardboard or foam spacers away from the equipment and set them aside.
- 4. Cut all plastic ties securing the equipment in place.
- 5. Remove the base frame assembly from the container and set it on the floor where you plan to assemble and use the equipment.

Before you begin, verify that you have received the following parts:

- Console box
- Base frame assembly
- Left and right upright supports
- Console bracket
- Handrail assembly
- Smaller box contains:
 - Dash buckets
 - Hardware kit
 - Assembly Guide
 - Dash bucket covers
 - Stop key and clip
 - Chest strap

Obtaining Service

Do not service the treadmill except for minor belt adjustments and maintenance tasks as described in the owner's manual. For more information regarding customer support numbers or a list of Precor authorized service dealers, visit the Precor web site at www.precor.com.

Required Tools

- 17 mm open-end wrench
- Level

Hardware Kit (not to scale)

The hardware kit shipped with this equipment contains the fasteners and other hardware components shown in the following table. Before you begin assembly, make sure that your hardware kit is complete. If not, please contact Precor Customer Support.




Figure 1: Hardware kit

Table 1. Hardware kit contents


| Number | Fasteners | | Quantity |
|----------|-----------|---|----------|
| 0 | | Socket head cap screw (5/16-inch x 3/4-inch) | 8 |
| 9 | | Flat washer (#10) | 6 |
| 8 | | Buttonhead cap screw (5/16-inch x 3/4-inch) | 6 |
| 4 | | Buttonhead cap screw (1/4-inch x 1/2-inch) | 7 |
| 6 | | Socket head cap screw (#10 x ½-inch) | 6 |
| 3 | | Split washer (5/16-inch) | 6 |
| Ø | | 5/32-inch hex wrench | 1 |
| 7 | | 3∕16-inch hex wrench | 1 |
| 0 | | 1/4-inch hex wrench with longer leg | 1 |

Getting Started 3


TRM 400 Series Assembly Guide 4

Table 2. Other components


Stop key and clip




Console bracket




Right and left dash bucket covers



Right and left dash buckets



Heart rate chest strap



Assembling the Equipment

CAUTION: The location of the On/Off switch is under the product label on the front of the treadmill. Make sure the power switch is in the Off position and the power cord is disconnected from its power source.




Figure 2: On/Off switch in Off position

Proper alignment and adjustment of the equipment is critical. When you install fasteners, leave room for adjustments. Do not fully tighten the fasteners until you are instructed to do so.

The following figure shows the names used in this manual for the major components of the equipment.




Figure 3: Major components of the treadmill

Assembling the Equipment 5

Assembling the Frame

To assemble the frame:

1. Remove the hood, by **loosening** the two front fasteners and two side fasteners on the hood using the 3/16-inch hex wrench.




Figure 4: Locations of hood fasteners

2. Lift the hood and set it aside.




Figure 5: Remove the hood

- 3. Position the left upright support onto the base frame side bracket. **Note:** The left upright support has a large hole on the inner side of it.
- 4. Ask your assistant to help you line up the mounting holes and secure the upright support using four 5/16-inch x 3/4-inch socket head screws, two in the side mounting holes and two in the front mounting holes. Partially tighten all four screws.




Figure 6: Upright support attachment

5. Repeat steps 3 and 4 to attach the right upright support using the four remaining 5/16-inch x 3/4-inch socket head screws and partially tighten.

Attaching the Handrail Assembly

The handrail assembly arrives with four cables already installed. The base unit data cable is rolled up and tucked inside the left tube. Before attaching the handrail assembly, unroll the cable and remove the kinks.

To attach the handrail assembly:

1. Ask your assistant to hold the handrail assembly while you feed the base unit data cable inside and completely down the left upright support.

Note: Make sure the cable connector rests on the floor at the base of the upright support.

CAUTION: Be aware of the handrail extensions when you are working around the front of the unit. It is easy to bump your head or sustain other injuries if you ignore the location of the handrail extensions.




Figure 7: Feed cable from handrail extension through upright support

2. Ask your assistant to hold the handrail assembly above the upright supports. Tip the assembly forward so the mounting brackets slide along the interior rails inside the upright supports. Align the mounting holes and secure the handrail using six 5/16-inch x 3/4-inch buttonhead cap screws and six split washers. Partially tighten the fasteners.

Important: Make sure the fasteners do not pinch the cable. Cables damaged by improper installation will not be covered by the Precor Limited Warranty.

Note: Thread the bottom hole first on either side. This will help line up the other holes.




Figure 8: Handrail attachment

3. Pull the cable connector through the large hole in the left upright support and attach it to the data port on the base unit frame.

Note: You will hear a click when it is fully connected.




Figure 9: Cable connection to lower board

TRM 400 Series Assembly Guide 8

To tighten the mounting screws:

1. Start at the base and use the ¼-inch hex key to alternately tighten the eight fasteners that secure the upright supports to the base assembly.

2. Use the 3/16-inch hex key to fully tighten the six screws that secure the handrail assembly to the upright supports.

Attaching the Console to the Treadmill

Before you begin, make sure there are four cables protruding upward from the handrail assembly.

To attach the console bracket:

1. Position the console bracket against the welded bracket holder on the handrail assembly as shown in the following figure.




Figure 10: Console bracket attachment

2. Secure it using three ¼-inch x ½-inch buttonhead screws.

Note: Do not fully tighten the screws until all three have been partially threaded.

Attaching the Cables to the Console

Four cables attach to the console. This guide feature helps ensure that the cables are not pinched when the console is attached to the treadmill.




Figure 11: Cable attachments on back of console

| Number | Cable or feature |
|----------|------------------------|
| 0 | Stop switch cable |
| 9 | Base unit data cable |
| 3 | Console ground cable |
| 4 | Touch heart rate cable |
| 6 | Cable retainer |

Attaching the Console to the Treadmill

TRM 400 Series Assembly Guide

To attach the cables to the console:

- 1. Ask your assistant to hold the console over the console bracket while you carefully route the following console cables:
 - a. Insert the stop switch cable (1) with the two connector tabs pointing down. You will feel the cable lock into place.
 - b. Insert the base unit data cable (2).
 - c. Once both of these cables are connected, tuck the cables into the left side of the cable retainer (5), as shown in the figure below.
 - d. Insert the console ground cable (3) with the round side positioned upward.
 - e. Insert the touch heart rate cable (4) with the front two tabs pointing down.
 - f. Once both of these cables are connected, tuck the cables into the right side of the cable retainer (5).

Important: Make sure that all four cables are tucked into the cable retainer before you place the console on the bracket. Place excess cable in the console recess where the cables insert.




Figure 12: Cable guide on back of console

2. Set the console onto the console bracket. It should sit flush on the bracket without gaps. If there is a gap, check to make sure that no cables are being pinched between the console and the console bracket.

Note: Do not secure the console to the bracket until instructed to do so.




Figure 13: Console should fit snuggly on console bracket

Attaching the Dash Buckets

Note: The fasteners used to secure the dash buckets to the console bracket also secure the console to the bracket.

The dash buckets fit on either side just behind the console. To position them, tilt them so that the bottom side rests on the handrail and the side tab is positioned behind the console and bracket.




Figure 14: Position of dash buckets on dash and handrail assembly

Important: To ensure proper assembly, perform the following steps in the order presented.

To attach the dash buckets:

1. Position the right dash bucket so that the mounting holes line up with the console bracket holes and the welded bracket on the handrail assembly.




Figure 15: Slide the dash bucket behind the console

2. Secure the dash bucket to the console bracket using two ¼-inch x ½-inch buttonhead screws. Fully tighten the screws.

Note: If the lower screw does not engage, remove the console and make sure that no cables are being pinched between the console and the console bracket.




Figure 16: Dash bucket and console attachment

Attaching the Console to the Treadmill

3. Secure the dash bucket to the welded bracket using two #10 x $\frac{1}{2}$ -inch socket head screws and two flat washers. Fully tighten the screws.

Note: Make sure the dash bucket is securely attached to the console bracket (step 2) before performing this step.




Figure 17: Dash bucket attachment to welded bracket

- 4. Repeat steps 1 through 3 to attach the left dash bucket.
- 5. Locate the three tabs on the right bucket cover and align them with the three slots along the edge of the right dash bucket.

Note: It is easier to attach the cover if you fit the lower edge into the dash bucket first.




Figure 18: Location of tab and lower edge

6. Attach the right dash bucket using one #10 socket head screw and one flat washer. Gently tighten the screw.

Important: Do not overtighten the #10 screw while attaching the bucket covers.

12




Figure 19: Attach the dash bucket cover

7. Repeat steps 5 and 6 to attach the left dash bucket.

Replacing the Hood

Before replacing the hood, plug in the treadmill and turn it on. If the treadmill does not work, check the following:

- Make sure you have connected the cable connector. See *Attaching the Cables to the Console.*
- Check that the treadmill on/off switch is in the On position.

Once you are confident that it is working, you can turn it off and unplug it before you attach the hood.

CAUTION: Turn the treadmill off and unplug it before you replace the hood.

To attach the hood:

1. Position the hood over the running belt so you can slide it through the upright supports from the rear. Align the hood with its four fasteners.




Figure 20: Replacing the hood

2. Use the 3/16-inch hex wrench to fully tighten the two side fasteners and the two front fasteners that secure the hood.




Figure 21: Front hood fasteners

Attaching the Console to the Treadmill

TRM 400 Series Assembly Guide 14

Completing Assembly

Once initial assembly is complete, there are a few things to do before the treadmill can be used:

- Attach the stop key
- Remove protective film
- Level the treadmill
- Check the alignment
- Adjust the running belt
- Break in the equipment

Attaching the Stop Key

The magnetic stop key fits into the nest on the stop switch assembly at the base of the console.




Figure 22: Stop key placement

For more information on using the emergency stop function and the safety clip, see the product *Owner's Manual*.

Removing the Protective Film

The treadmill ships with a protective film over the Precor logos and on the face of the console. To remove the film, grasp the edge of it and peel it off the equipment.

Leveling the Treadmill

Important: Before using the treadmill, make sure it is completely level and that it sits evenly on the floor.

To ensure that the treadmill is completely level, you should check it in two directions:

- from side to side (across the belt)
- from front to back (along the belt)

The treadmill should be leveled to *center* or *zero*, depending on the type of level you use. If adjustments are needed, adjust one rear foot at a time.

To check the level of the treadmill:

1. Place the level across the treadmill belt as shown in the following figure. Make sure the level reads at center or zero, depending on the type of level you use.




Figure 23: Level position across belt

2. Place the level along the belt front to back as shown in the following figure. Make sure the level reads at center or zero, depending on the type of level you use.




Figure 24: Level position along belt

To level the treadmill:

- 1. Ask your assistant to lift the rear portion of the treadmill. **Important:** Use proper lifting techniques when lifting the treadmill.
- 2. Loosen the upper lock nut with a 17 mm open-end wrench and rotate the rear foot to raise or lower the treadmill.



Figure 25: Lock nut location and foot adjustment

3. Fully tighten the lock nut and lower the treadmill to the floor.




Figure 26: Proper positioning

Note: The distance between the lock nut and foot should be no more than ³/₄ inch (2 cm).

4. Repeat this procedure to adjust the other rear foot if needed.

Checking the Alignment

Proper belt alignment allows the belt to remain centered and ensures smooth operation. Realigning the belt takes a few simple adjustments. If you are unsure about this procedure, call Precor Customer Support. Refer to *Obtaining Service*.

CAUTION: Special care must be taken when aligning the running belt. Turn Off the treadmill while adjusting or working near the rear roller. Remove any loose clothing and tie back your hair. Be very careful to keep your fingers and any other object clear of the belt and rollers, especially in front of the roller and behind the deck. The treadmill will not stop immediately if an object becomes caught in the belt or rollers.

To check the alignment:

- 1. The treadmill has adjustable rear feet. Make sure that the running surface is level before aligning or adjusting the running belt. For more information, see *Leveling the Treadmill*.
- 2. Connect the power plug to an appropriate dedicated circuit and turn the unit **On**.
- Stand beside the treadmill and press QUICKSTART.
 Note: If needed, enter the password. Refer to your owner's manual. The running belt starts automatically after a 3-second countdown appears on the display.
- 4. Increase the treadmill belt speed until the display shows a speed of 3 mph (5 kph).

CAUTION: If you hear any chafing or see that the running belt appears to be getting damaged, stop the running belt immediately by pressing the red STOP button. Contact Precor Customer Support.

- 5. Walk around to the rear of the unit and observe the belt for a few minutes. The belt should run centered along the running bed. If the belt drifts off center, you will need to make adjustments. Refer to the next section.
 - **Important:** If the belt needs alignment, make the adjustments at once. Failure to align the belt may cause the belt to tear or fray, which is not covered by the Precor Limited Warranty.
- 6. To stop the running belt, press the red **STOP** button.
- 7. Turn the treadmill **Off**.

Completing Assembly 15

TRM 400 Series Assembly Guide 16

Adjusting the Running Belt

If you are unsure about adjusting the running belt, contact Precor Customer Support. Refer to *Obtaining Service*.

CAUTION: For your safety, use the power switch to turn Off the treadmill before making any adjustments. Do not adjust the running belt when someone is standing on the unit.

To adjust the running belt:

1. Locate the right belt adjustment bolt in the rear end cap of the treadmill.




Figure 27: Belt adjustment bolt location

- 2. To determine left and right, stand at the rear of the treadmill and face the display. Make all belt adjustments on the right rear corner bolt using the ¼-inch hex key.
 - If the belt is off center to the LEFT, turn the adjusting bolt ¼ turn counterclockwise, which moves the running belt to the right.
 - If the belt is off center to the RIGHT, turn the bolt 1/4 turn clockwise, which moves the belt to the left.

Important: Do not turn the adjusting bolt more than $\frac{1}{4}$ turn at a time. Overtightening the bolt can damage the treadmill.

3. Recheck the alignment of the running belt.

Breaking in the Equipment

Precor equipment does not require an actual break-in period. However, moving components such as belts, gears, and bearings can settle while the equipment is being stored or shipped. This can cause the equipment to operate with a small amount of roughness or noise when it starts up for the first time.

The equipment usually returns to smooth operation after a day or two of normal use. If it does not, contact your dealer for assistance. For more information, refer to your owner's manual.



Precor Incorporated 20031142nd Ave NE P.O. Box 7202 Woodinville, WA USA 98072-4002 1-800-347-4404 Precor is a registered trademark of Precor Incorporated. Copyright 2014 Precor Incorporated. Specifications subject to change without notice.

www.precor.com

NOTICE:

Precor is widely recognized for its innovative, award winning designs of exercise equipment. Precor aggressively seeks U.S. and foreign patents for both the mechanical construction and the visual aspects of its product design. Any party contemplating the use of Precor product designs is hereby forewarned that Precor considers the unauthorized appropriation of its proprietary rights to be a very serious matter. Precor will vigorously pursue all unauthorized appropriation of its proprietary rights.



Precision™ Series TRM 400 Treadmill Assembly Guide 303158-110 rev A, en March 2014



Residential Cardiovascular Equipment

Limited Warranty

For Elliptical Fitness Crosstrainers™:

- Precision Series (EFX® 447, 425, and 423)
- Energy Series (EFX® 245, 225, 222, and 221)

For Treadmills:

- Precision Series (TRM 445 and 425)
- Energy Series (TRM 243, 223, and 211)

PLEASE READ THESE WARRANTY TERMS AND CONDITIONS CAREFULLY BEFORE USING YOUR PRECOR INCORPORATED PRODUCT. BY USING THE EQUIPMENT, YOU ARE CONSENTING TO BE BOUND BY THE FOLLOWING WARRANTY TERMS AND CONDITIONS.

Limited Warranty

Precor Incorporated warrants all new Precor products to be free from defects in materials and manufacture for the warranty periods set forth below. The warranty periods commence on the invoice date of original purchase. This warranty applies only against defects discovered within the warranty period and extends only to the original purchaser of the product. Parts repaired or replaced under the terms of this warranty will be warranted for the remainder of the original warranty period only. To make a claim under this warranty, the buyer must notify Precor or his or her authorized Precor Distributor within 30 days after the date of discovery of any nonconformity and make the affected product available for inspection by Precor or its service representative. Precor's obligations under this warranty are limited and set forth below.

Warranty Periods and Coverage

Represented models of residential products used in the home are warranted for the following periods:

| | Precision Series | Energy Series |
|-----------------------------|-------------------------|----------------------|
| Structural frame and welds: | Lifetime | Lifetime |
| Parts and wear items: | 10 years | 5 years |
| Console: | 3 years | 3 years |
| Labor: | 1 year | 1 year |

The following section defines coverage for options and accessories.

Options / Accessories

Many options or accessories have components that are connected internally or mounted inside the electronic console. The following guidelines determine the warranty for these components. If the internal components are installed by the factory or by an authorized dealer or distributor as part of the original sale and delivery, they have a warranty that is identical to the warranty of the equipment in which they are connected or mounted. If the internal components are not installed by the factory or by an authorized dealer or distributor as part of the original sale and delivery, they have a 90-day parts and labor limited warranty. All components that are not internally connected have a 90-day parts only limited warranty. Satisfactory proof of purchase is required in all cases.

Conditions and Restrictions

This warranty is valid only in accordance with the conditions set forth below:

- 1. The warranty applies to the Precor product only if:
 - a. It has been serviced by a Precor Authorized Service Provider and/or Precor Certified facility staff.
 Outside of North America, the product must have been serviced by the local Precor sales office or an Authorized Precor Distributor.
 - b. It remains in the possession of the original purchaser and proof of purchase is demonstrated.
 - c. It has not been subjected to accident, misuse, abuse, improper service, or non-Precor modifications.
 - d. Claims are made within the warranty period.

- This limited warranty does not cover damage or equipment failure caused by electrical wiring not in compliance with electrical codes or Precor owner's manual specifications, or failure to provide reasonable and necessary maintenance as outlined in the owner's manual.
- 3. This limited warranty applies only to Precor products designed for residential use only and is void in the event such products are used in a nonresidential environment or installed in a country other than the country where such products were originally sold.
- 4. Moving parts bolted to the structural frame are not included in the "Structural Frame" warranty (for example, moving arms, seat and back pad assemblies, cross ramp assemblies, position adjustments, and so on).
- Precor is not responsible for Internet connectivity to its products. This restriction applies to services, such as those provided by an Internet Service Provider (ISP), and also to hardware related to Internet connectivity, such as Ethernet cabling, routers, servers and switches.
- 6. Precor is not responsible for the quality of television, video, audio, or other media supplied to its products. This restriction applies to services, such as those provided by a cable or satellite television provider; to signal strength and clarity; and also to hardware related to the reception and delivery of television, video, audio, and other media. Such hardware may include (but is not limited to) audio, video, and radio-frequency (RF) cabling, connectors, receivers, modulators, combiners, distribution amplifiers, splitters, and so on.
- 7. Precor cannot guarantee that the heart rate measurement system on its products will work for all users. Touch heart rate performance may vary based on a user's physiology, fitness level, age, and other factors. You may experience an erratic readout if your hands are dry, dirty, or oily, or if the skin on your palms is especially thick. Wearing hand lotion can also cause an erratic readout. In addition, make sure that the sensors

- are clean to ensure proper contact can be maintained. If the touch heart rate feature does not work for you, Precor recommends that you use a chest transmitter strap.
- 8. Precor does not warranty the work or product of third party companies (e.g., head end systems, low voltage wiring, etc.)
- Except in Canada, Precor does not pay labor outside the United States
- 10. Warranties outside the United States and Canada may vary.

Please contact your Precor sales office or local Distributor for details.

This limited warranty shall not apply to:

- 1. Software version upgrades.
- 2. Software defects that do not materially and negatively affect the exercise functionality of the product under normal use conditions at the time of installation.
- 3. Cosmetic items, including, but not limited to the following: grips, seats, and labels, or other items, the exterior of which has been damaged or defaced as a result of abuse, misuse, accident, improper service or installation, mishandling, or modification in design or construction not authorized by Precor including, without limitation, use or incorporation of any non-OEM (Original Equipment Manufacturer) replacement parts.
- 4. Cosmetic, structural, or functional damage (including rust, corrosion and unusual wear) caused by failure to follow the maintenance procedures described in the owner's manual.
- 5. Repairs performed on Precor equipment missing a serial number or with a serial tag that has been altered or defaced.

- 6. Service calls to correct installation of the equipment or instruct owners on how to use the equipment.
- 7. Pickup, delivery, or freight charges involved with repairs.
- 8. Any labor costs incurred beyond the applicable labor warranty period.

Disclaimer and Release

The limited warranties provided herein are the exclusive warranties given by Precor and supersede any prior, contrary or additional representations, whether oral or written. ANY IMPLIED WARRANTIES, INCLUDING THE WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE THAT APPLY TO ANY PARTS DESCRIBED ABOVE ARE LIMITED IN DURATION TO THE PERIODS OF EXPRESS WARRANTIES GIVEN ABOVE FOR THOSE SAME PARTS. PRECOR HEREBY DISCLAIMS AND EXCLUDES THOSE WARRANTIES THEREAFTER. Some states do not allow limitation on how long an implied warranty lasts, so the above limitations may not apply to you. PRECOR ALSO HEREBY DISCLAIMS AND EXCLUDES ALL OTHER OBLIGATIONS OR LIABILITIES, EXPRESS OR IMPLIED, ARISING BY LAW OR OTHERWISE, WITH RESPECT TO ANY NONCONFORMANCE OR DEFECT IN ANY PRODUCT, INCLUDING BUT NOT LIMITED TO: (A) ANY OBLIGATION, LIABILITY, RIGHT, CLAIM OR REMEDY IN TORT, WHETHER OR NOT ARISING FROM THE NEGLIGENCE OF PRECOR OR ITS SUPPLIERS (WHETHER ACTIVE, PASSIVE OR IMPUTED); AND (B) ANY OBLIGATION, LIABILITY, RIGHT, CLAIM, OR REMEDY FOR LOSS OF OR DAMAGE TO ANY EOUIPMENT. This disclaimer and release shall apply even if the express warranty set forth above fails of its essential purpose.

Exclusive Remedies 7

Exclusive Remedies

For any product described above that fails to conform to its warranty, Precor will provide, at their option, one of the following: (1) repair; (2) replacement; or (3) refund of the purchase price. Precor Limited Warranty service may be obtained by contacting the authorized Distributor from whom you purchased the item. Precor compensates Precor Authorized Servicers for warranty trips within their normal service area to repair equipment at the owner's location. You may be charged a trip charge outside the service area. THESE SHALL BE THE SOLE AND EXCLUSIVE REMEDIES OF THE BUYER FOR ANY BREACH OF WARRANTY.

Exclusion of Consequential and Incidental Damages

PRECOR AND/OR ITS SUPPLIERS SHALL HAVE NO OBLIGATION OR LIABILITY, WHETHER ARISING IN CONTRACT (INCLUDING WARRANTY), TORT (INCLUDING ACTIVE, PASSIVE, OR IMPUTED NEGLIGENCE AND STRICT LIABILITY), OR OTHERWISE, FOR DAMAGE TO THE EOUIPMENT, PROPERTY DAMAGE. LOSS OF USE, REVENUE OR PROFIT, COST OF CAPITAL, COST OF SUBSTITUTE EQUIPMENT, ADDITIONAL COSTS INCURRED BY BUYER (BY WAY OF CORRECTION OR OTHERWISE) OR ANY OTHER INCIDENTAL, SPECIAL, INDIRECT, OR CONSEQUENTIAL DAMAGES, WHETHER RESULTING FROM NONDELIVERY OR FROM THE USE. MISUSE OR INABILITY TO USE THE PRODUCT. This exclusion applies even if the above warranty fails of its essential purpose and regardless of whether such damages are sought for breach of warranty, breach of contract, negligence, or strict liability in tort or under any other legal theory. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation might not apply. This warranty gives you specific legal rights, and you may also have other rights, which vary state to state.